

**porodo**  
LIFESTYLE

## Head Massager User Manual



Model No: PD-LSHDMSG4-BK

### SAFETY INSTRUCTIONS

Please read ALL instructions carefully before using the product for the first time. We recommend that you keep this manual for future reference, even if you are familiar with the product. The basic safety precautions should always be followed. Failure to comply with this manual may cause fire, electric shock, damage to the product, and serious injury.

- This product is not intended to diagnose or treat any medical condition or to replace your healthcare professional. Always consult your physician before use any massagers. Please STOP using and consult your healthcare professional immediately when you feel uncomfortable during use.
- This massager should not be used by children younger than 6 years or by persons with reduced physical, sensory, or mental capabilities or lack of experience and knowledge, unless they are supervised or are given instruction concerning the use of this product in a safe way and understand the hazards involved.
- **DO NOT** use this head massager if you have any of the following diseases or conditions:  
Skin infection or other skin disease.  
Heart disease or recorded, acute diseases, malignant tumors, or any other unhealthiness.  
Pregnancy or period.  
Patients with blood diseases such as bleeding tendency, osteoporosis, soft tissue diseases or stroke.
- **DO NOT** use this head massager on:  
Skin areas with damage, redness, inflammation, congestion and other uncomfortable symptoms.  
The surgical site of your body.
- Please **DO NOT** use the product if you are drunk.  
**DO NOT** use it while walking or driving.

- **Never** use the massager while it is charging.
- Keep the massager away from high heat, and/or corrosive environment.
- Please remove hairpins or objects on your head that may affect your massaging.
- Please comply with the safety regulations when using in a specific environment.
- **DO NOT** use sharp objects to scratch this product.
- The product is intended for personal use, it should **NOT** be used for the therapy purpose.
- Never operate the product if it has been broken or has a damaged charging cable.
- If there is any abnormal phenomenon during use, please cut off the power immediately. **Do not** disassemble or repair it by yourself.
- Please use the charging equipment offered by the seller to charge the product.
- Only use the adaptor (5V 1A, not included) to connect to the charging cable and recharge the head massager.

### PACKAGE CONTENTS

- 1 x Head Massager
- 1 x Charging Cable
- 1 x User Manual

### SPECIFICATIONS

Product Name	Head Massager
Model Number	PD-LSHDMSG4-BK
Rated Charging Voltage	5V=
Rated Power	5W
Session Time	10 Minutes
Battery Capacity	1200mAh

### PRODUCT FEATURES

- 2 Massage Speeds
- Skin-Friendly
- Light and Compact
- One-Button Control
- IPX7 Waterproof
- Two Massage Speeds



### KNOW YOUR HEAD MASSAGER

Featured four 3D silicone massage heads that are equipped with 68 contact points. Electric Head Massager replicates the circular thumb kneading technique of a professional massager. It rubs and massages the scalp to soothes nerves and relieves pressure. Use it on your neck, shoulders, back, legs, and any part of your body that need to experience the comfortable sensation. With IPX7 waterproof design, this massager can be used during a bath or while shampooing.

#### BUTTONS AND FUNCTIONS

- Indicator Light
- Silicone Massage Head
- Main Button
- Charging Interface

#### Main Button:

**Power On**


Press and hold the main button for one second to turn on the massager.

**To Switch Speed**

After starting, short press once for speed switching

**Power Off**

Press and hold the button for three seconds to power off



### PREPARATION BEFORE USE

#### PREPARATION

- Check whether the products and accessories are complete. Do not use them if they are damaged.
- Fully charge the battery before initial use.

#### CHARGING

1. Place the magnetic suction head on the charging cable to the charging interface at the bottom of the massager.
2. Attach the charging cable to the power adaptor (5V 1A, not included), and plug it into the power outlet.
3. While charging, the light indicator on the main unit flashes in red. After 2 hours, the light indicator will turn green, and the charging process is completed.
4. Once the massage is fully charged, it can be used for up to 150 minutes each time. (There will be differences due to the different massage speed).
5. When the product power is low, the machine will shut down automatically.

**Note:** The massager will not operate while charging, please remember to remove the cable after charging.

### PREPARATION INTRODUCTION

1. Press and hold main button for a second, the indicator light turns green and the default shiatsu mode begins at fast speed immediately.
2. To change mode, short press the button. The massage mode changes from fast speed to slow speed, and the green indicator starts to flash
3. Put the massage heads on the body to start the massage, relax your body completely while using this product. This massager can be used in the shower and bath as well.
4. After finishing massage. Long press the button for three seconds, the machine shuts down and the indicator light turns off.

**Note:** The product will shut down automatically after 10 minutes of no-operation.

### CHARGING

Product Name	Head Massager
Green	Fast Speed / Charging completed
Flashing Green	Slow Speed
Flashing Red	Charging is in Progress

### CLEANING AND MAINTENANCE

#### CLEANING

- The four silicone massage heads are removable. You can detach the massager heads from the unit and wash them with water. Wipe them and air dry.
- Spot clean the surface with a soft and slightly damp sponge.

#### STORAGE

- Please put the product back in box after use. Store it in a safe, dry, and cool place.
- **DO NOT** put any heavy object on the massager.
- Store the product in a well-ventilated place, avoid intense sunlight illumination and corrosive gas erosion.
- Recharge and inspect the massager before a long period of storage.

### TROUBLESHOOTING

Troubleshoot your problem by using the chart below. If the head massager still does not operate correctly, it may be a defective unit. Please contact a qualified technician or contact our support team if it's within the warranty. **DO NOT** try to repair it by yourself. Otherwise, there is a risk of electric shock.

Problem	Possible Cause	Solution
Fail to turn on the massager	The battery power is low	Please recharge the massager
Weak Massaging	The battery supply is not enough	Please charge the massager immediately

## مدلك الرأس دليل الاستخدام



Model No: PD-LSHDMSG4-BK

### تعليمات السلامة

يرجى قراءة جميع التعليمات بعناية قبل استخدام المنتج لأول مرة. نوصي بالاحتفاظ بهذا الدليل للرجوع إليه في المستقبل. حتى لو أنت على دراية بالمنتج يجب أن تكون احتياطات السلامة الأساسية دائماً ملتحفة. قد يؤدي عدم الامتثال لهذا الدليل إلى إعادة حدوث صدمة كهربائية و تلف المنتج، وإصابة خطيرة.

لا يعرف هذا المنتج أي تشخيص أو علاج أو حالة طبية أو استئصال أخصائي الرعاية الصحية الخاص بك. دائماً استشر طبيبك من قبل استخدام أي مدلك. يرجى التوقف عن استخدام واستشارة الرعاية الصحية احترافي الخاصة بك على الفور عندما تشعر بعدم الراحة أثناء استخدام.

لا ينبغي استخدام هذا المدلك من قبل الأطفال الذين تقل أعمارهم عن 6 سنوات أو أقل من ذلك. والأشخاص الذين يعانون من ضعف القدرات الجسدية أو الحسية أو العقلية أو نقص الخبرة والمعرفة. ما لم يتم الإشراف عليهم أو إعطائهم تعليمات فيما يتعلق باستخدام هذا المنتج بطريقة آمنة وهم المخاطر التي تنطوي عليها.

لا تستخدم جهاز مساج الرأس هذا إذا كنت تعاني من أي من الأمراض التالية أو الحالات:  
عدوى الجلد أو مرض جلدي آخر  
أمراض القلب أو الأمراض الحادة أو الأورام الخبيثة أو أي أمراض أخرى الحمل أو الدورة الشهرية  
لا تستخدم جهاز مساج الرأس هذا إذا كنت تعاني من أي من الأمراض التالية أو شروط:  
عدوى الجلد أو مرض جلدي آخر  
أمراض القلب أو الأمراض الحادة أو الأورام الخبيثة أو أي أمراض أخرى الإضرار بالصحة  
الحمل أو الدورة الشهرية  
مرض الدم مثل النزيف ومشائشة العظام و  
أمراض الأنسجة الناعمة أو انسكحة الدماعية

لا تستخدم جهاز مساج الرأس هذا في مناطق الجلد المصابة بالحرق والاحمرار والتقيح والاحتقان وغيرها من أعراض غير مريحة.  
الموقع الجراحي للحسك

من فضلك لا تستخدم المنتج إذا كنت في حالة سكر.  
لا تستخدمه أثناء المشي أو القيادة.

- لا تستخدم جهاز التدليك أبداً أثناء الشحن.
- احتفظ بالمدلك بعيداً عن الحرارة العالية و/أو البيئة المسببة للتآكل.
- يرجى إزالة جاييس الشعر أو الأشياء الموجودة على رأسك والتي قد تركز على تدليك رأسك.
- يرجى الالتزام بالوثاق السلامة عند الاستخدام في بيئة خاصة.
- لا تستخدم أثناء حالة لخدش هذا المنتج.
- المنتج مخصص للاستخدام الشخصي، ولا ينبغي استخدامه لغرض المعالجة.
- لا تقم مطلقاً بتشغيل المنتج إذا كان مكسوراً أو به كابل شحن تلف.
- إذا كان هناك أي ظاهرة غير طبيعية أثناء الاستخدام، يرجى قطع التيار الكهربائي فوراً. لا تفككها أو تصلحها بنفسك.
- يرجى استخدام معدات الشحن التي يقدمها البائع لشحن المنتج.
- استخدم فقط المحول (ه فولت أمير. غير مرجح) للاتصال بكابل الشحن. وشحن مدلك الرأس.

### محتويات الحزمة

- جهاز مساج للرأس ١ ×
- كابل شحن ١ ×
- دليل المستخدم ١ ×

### مواصفات

مدلك الرأس	اسم المنتج
PD-LSHDMSG4-BK	رقم الموديل
- فولت ٥	تصنيف الجهد لشحن
واط ٥	القوة المصنفة
دقائق ١	وقت الجلوس
ملي أمبير - ٢	قدرة البطارية

### مميزات المنتج

- لطيف على البشرة
- تحكم بزر واحد
- سرعة تدليك ٢
- خفيف وصغير الحجم
- مقاوم للماء IPXV



- خفيف وحجمه صغير
- التحكم بزر واحد
- سرعة تشغيل ٢
- مقاوم للماء IPXV

### تعرف على جهاز تدليك رأسك

ظهرت أربعة رؤوس تدليك سيليكون ثلاثية الأبعاد مزودة بـ ٦٨ نقطة اتصال ، مدلك الرأس الكهربائي يكرر تقنية عجن الإبهام الدائري للمدلك محترف. يترك ويدلك فروة الرأس يهدئ الأعصاب ويخفف الضغط. استخدمه على رقبك وكتفك وظهرك و الساقين وأي جزء من جسمك يمكن استخدامه هذا ، IPXV يحتاج إلى تجربة مريحة مع تصميم مقاوم للماء المدلك أثناء الاستحمام أو أثناء غسل الشعر بالشامبو

### أزرار و وظائف

- رأس تدليك سيليكون
- واجهة لشحن
- ضوء المؤشر
- الزر الرئيسي

### زر رئيسي

### تشغيل


اضغط مع الاستمرار على الزر الرئيسي لمدة ثانية واحدة لتشغيل المدلك

### التنين من سرعة التدليل

بعد البدء ، اضغط مرة واحدة لتبديل السرعة

### إيقاف

اضغط مع الاستمرار على الزر لمدة ثلاث ثواني لإيقاف التشغيل



### التحضير قبل الاستخدام

### التحضير

- تحقق مما إذا كانت المنتجات والمخلفات كاملة لا تستخدمهم في حالة تلفهم
- الشحن البطارية بالكامل قبل الاستخدام الأولي

### الشحن

١ ضع رأس الضغط المغناطيسي على كابل الشحن لشحن وجهه في الجزء السفلي من جهاز التدليك  
٢ قم بتوصيل كابل الشحن بمحول الطاقة أو فولت أمير. غير مرفق، و قم بتوصيله بمكان الطاقة  
٣ أثناء الشحن، يتحول المؤشر لرموز الموجود على الوحدة الرئيسية إلى رماد باللون الأحمر بعد ٢ ساعات ، سيتحول مؤشر الضوء إلى اللون الأخضر، وتكتمل عملية الشحن  
٤ بمجرد أن يتم شحن المدلك بالكامل ، يمكن استخدامه لمدة تصل إلى ٥٠ دقيقة لكل وقت استكون هناك اختلافات بسبب اختلاف سرعة التدليك  
٥ عندما تكون طاقة المنتج منخفضة ، سوف تغلق الآلة أوتوماتيكياً

### زر رئيسي

### تشغيل

اضغط مع الاستمرار على الزر الرئيسي لمدة ثانية واحدة لتشغيل المدلك

### ملاحظة: لن يعمل المدلك أثناء الشحن ، يرجى تذكر ذلك. قم بإزالة الكابل بعد الشحن

### مقدمات التحضير

١ اضغط مع الاستمرار على الزر الرئيسي لمدة ثانية ، يتحول ضوء المؤشر إلى اللون الأخضر وهذا هو شقشقة الأقران بسرعة عالية على الفور  
٢ لتغيير الوضع ، اضغط لفترة وجيزة على الزر ، يتغير وضع التدليك من سرعة عالية للبطء السرعة ، وهذا المؤشر الأخضر في الوضع  
٣ ضوء رأس التدليك على الجسم بعد التدليك ، يرجى حسك  
٤ ماعا أنك تستخدم هذا المنتج ، يمكن استخدام هذا المدلك أثناء الاستحمام والحمام كذلك  
٥ بعد الانتهاء من التدليك، اضغط لفترة طويلة على الزر لمدة ثلاث ثواني ، الجهاز يتم إيقاف تشغيله ويطفئ ضوء المؤشر

**ملاحظة:** سيتم إغلاق المنتج تلقائياً بعد ١٠ دقائق من الوجود عملية

### الشحن

مدلك الرأس	اسم المنتج
للسرعة/الشحن اكتمل	لون أخضر
سرعة بطيئة	واضئ باللون الأخضر
جاري الشحن	وميض أحمر

### التنظيف والصيانة

### التنظيف

- رؤوس التدليك الأربعة المصنوعة من السيليكون قابلة للإزالة بمحكك. فصل رؤوس المدلك من الوحدة وغسلها بالماء. امسحها وجففها بالهواء.
- نظف السطح باستخدام قطعة ناعمة ومبللة قليلاً.

### التخزين

- يرجى إعادة المنتج في الصندوق بعد الاستخدام، قم بتخزينه في مكان آمن وجاف وبارد -
- لا تضع أي شيء ثقيل على جهاز التدليك
- قم بتخزين المنتج في مكان جيد التهوية، وتجنب الرضاء الشديدة لأشعة الشمس -
- وتكامل الغبار المسببة للتآكل
- إعادة شحن وتفتيش المدلك قبل فترة طويلة من التخزين -

### اكتشاف الأخطاء وأصلاحها

قم باكتشاف مشكلتك وإصلاحها باستخدام الرسم البياني أدناه. إذا كان لا يزال مدلك الرأس لا يعمل بشكل صحيح ، فقد تكون الوحدة معيبة. يرجى الاتصال بشي مؤهل أو الاتصال بفرق الدعم الخاص بنا إذا كان ضمن الضمان. لا تحاول أن تصلحه بنفسك. خلاف ذلك ، هناك خطر حدوث صدمة كهربائية

الحل	السبب المحتمل	المشكلة
الرجاء إعادة شحن المدلك	قوة البطارية منخفضة	فشل في تشغيل المدلك
الرجاء إعادة شحن المدلك على الفور	عدم كفاية شحن البطارية	المدلك ضعيف